

## Hydrant accessories

### Standpipes for underground hydrants

No.	Description	Material	Index
1.	Standpipe DN 80	AK11-A1Si11	1-424 000 080 01
2.	Standpipe DN 100	AK11-A1Si11	1-424 000 100 01

They are used to collect water from underground hydrants.

### Wrenches for hydrants and valves

No.	Description	Material	Index
3.	Overground hydrant wrench „K4”	St3S ocynk	1-424 000 000 02
4.	Fire hose wrench „K2”	St3S ocynk	1-424 000 000 03
5.	Storz coupling and valve wrench	St3S ocynk	1-424 000 000 04
6.	Overground hydrant cover wrench „K6”	St3S ocynk	1-424 000 000 06
7.	Storz coupling wrench „K3”	St3S ocynk	1-424 000 000 05
8.	Underground hydrant, gate valve wrench and manhole covers „T”	St 2/ EN-GJS-500-7	1-424 000 000 00

They are used for opening and closing overground and underground hydrants and gate valves.

### Overground hydrant storz couplings

No.	Description	Material	Index
9.	Storz coupling (aluminum) 75, 100	AK11	1-422 000 000 00
10.	Storz coupling (plastic) 75	ABS	1-422 000 000 01

They are used to connect a fire hose.

### Overground hydrant covers

No.	Description	Material	Index
11.	Cover for overground hydrant 75 DN80	EN-GJL-250	1-422 000 000 02
12.	Cover for overground hydrant 75 DN80	Polyethylene HDPE	1-422 000 000 03
13.	Cover for overground hydrant 75 DN80 fang	Plastic ABS	1-422 000 000 04
14.	Cover for overground hydrant 75 DN80 fang	Aluminium AK11	1-422 000 000 05
15.	Cover for overground hydrant 110 DN100 fang	Plastic ABS	1-422 000 100 04
16.	Cover for overground hydrant 110 DN100 fang	Aluminium AK11	1-422 000 100 05
17.	Cover for overground hydrant 110 DN100	Aluminium AK11	1-422 000 100 06

They are used to secure the overground hydrant outlets.

### Hydrant drainage cover DN 80, DN 100 and DN 150

No.	Description	Material	Index
18.	Cover drainage/clamping bands	HDPE	1-419 100 080 00

It is used to prevent drainage and outwashing against the ground around hydrant. Designed for all types of hydrants with a diameter DN 80, 100, 150.